

## BoostedNW GM1 Adapter Emulator Use instructions

When using with a Cobra MotronicRT R6 the cable should be plugged into the adapter like this (MotronicRT R6 cables differ from ostrich cables)



When using with a Moates Ostrich/Ostrich2 Unit & cable, the cable should be plugged into the adapter like this(below):

