

Example of direction to plug Cobra MotronicRT R6 cable into socket, the arrow side goes to the same side as the notch that should be on the chip socket REGARDLESS OF THE ADAPTER(GM1, GM2, etc)

